



LOW-RISE CONDO DEVELOPMENT

COMMUNITY PARK

SWM

SUMMIT HILL DRIVE

SUMMIT HILL DRIVE

TARBOX AVENUE

TARBOX AVENUE

GOODEVE AVENUE

ADDISON STREET

SUMMIT HILL DRIVE

SUMMIT HILL DRIVE

UPLANDS AVENUE

UPLANDS AVENUE

NEW HOLLAND DRIVE

PORTRAIT STREET

BORRALS COURT

RICHVIEW TRAIL

LOST HOLLOW DRIVE

SHIREHORSE PLACE

STRONG WAY

GOODEVE AVENUE

ADDISON STREET

CELTIC AVENUE

SMART WAY

VERLE WAY

AIRPORT ROAD

ASPHALT LANE

AIRPORT ROAD

CRANSTON DR

35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45

BLOCK 201  
1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20

108  
109  
110